

Connecting your RECEIVER - DVD - TV - VCR - GAME



- Cable from Cable Outlet to IN on Receiver
- Cable from OUT on Receiver to IN on VCR.
- Cable from OUT on VCR to IN on TV.
- Audio/Video Cables from Game to Audio/Video IN on VCR.
- Audio/Video Cables from DVD to Audio/Video IN on TV.