


Connecting your RECEIVER - DVD - TV - VCR



- Cable from Cable Outlet to IN of Receiver.
- Cable from OUT on Receiver to IN on VCR.
- Cable from OUT on VCR to IN on TV.
- Audio/Video cables from OUT on DVD to Audio/Video IN on TV.